
△

4.1 Installation within a control cabinet

CN

50mm



	3.5N.m		
	u i gŭ ou ti g,ŭ eŭoŭw œ‰ŭ e dŭ pŭ oɹbi ti ɻŭewsŭ oŭ se ɻŭ heŭ ɹ ɹe.ŭ i		
CN			

*

*Note1: DIP switch function description

Toggle up	OFF (Terminal resistance disconnected)	OFF (Terminal resistance disconnected)	I (Input current signal)	250R AI (AI input impedance)
Toggle down	ON (Terminal resistance connected)	ON (Terminal resistance connected)	U (Input voltage signal)	500R AI (AI input impedance)

6. Indicator and LED panel description

